



TABELA KARTRIDŻY I DRUKAREK HP

Numer katalogowy

catalog19456

Kod producenta

www_tusze_info_19456

Producent

Komputery SONET

Opis produktu

TABELA DRUKAREK I ICH KARTRIDŻY

Symbol	Kolor	Model drukarki HP
51604A		ThinkJet
51606C		PaintJet
51625A 25		DeskJet 200cci / 310 / 311 / 320 / 340 / 340c / 340cbi / 400 / 400l / 420c / 500c / 540 / 550c / 560c DeskWriter 310 / 320 / 340 / 540 / 550c / 560c / c
51626A 26		DesignJet 200 / 220 / 600 / GL-2 / w DeskJet / 200cci / 400 / 400l / 420c / 500 / 500c / 505k / 510 / 520 / 540 / 550c / 560c / c / plus DeskWriter / 510 / 520 / 540 / 550c / 560c / c fax 200 / 300 / 310 / 700 / 750 / 900 / 950 OfficeJet / 300 / 310 / 320 / 330 / 350 / lx
51629A 29		DeskJet 600 / 600c / 660c / 660cse / 670c / 670tv / 672c / 680c / 682c / 690c / 692c / 693c / 694c / 695c / 695cci / 697c DeskWriter 600 / 660c / 670c / 680c / 694c fax 910 / 920 OfficeJet 500 / 520 / 570 / 580 / 590 / 600 / 610 / 630 / 635 / 700 / 710 / 720 / 725 PSC 370 / 380
51633M 33		DeskJet 310 / 311 / 320 / 340 / 340c / 340cbi / Portable DeskWriter 310 / 320 / 340
51640A 40B		CopyJet / M DesignJet 230 / 250C / 330 / 350C / 430 / 450C / 455C / 488C / 650C / 650PS DeskJet 1200
51640C 40C		Color Copier 210 / 210LX CopyJet / M DeskJet 1200 / 1600c / 1600cm
51640M 40M		Color Copier 210 / 210LX CopyJet / M DeskJet 1200 / 1600c / 1600cm
51640Y 40Y		Color Copier 210 / 210LX CopyJet / M DeskJet 1200 / 1600c / 1600cm
51641A 41		Color Copier 110 / 120 DeskJet 1000cse / 1000cxi / 1100c / 820c / 820ce / 820cxi / 850c / 850cxi / 855c / 855cse / 870cse / 870cxi OfficeJet pro 1150c / pro 1150cse
51645A 45		Color Copier 110 / 120 / 140 / 145 / 150 / 155 / 160 / 170 / 180 / 190 / 210 / 210LX / 260 /

		270 / 280 / 290 DesignJet 700 / 750C / 750C plus / 755CM / 755CM plus DeskJet 1000cse / 1000cxi / 1100c / 1120c / 1125c / 1180 / 1220c / 1220ps / 1280 / 1600c / 1600cm / 6122 / 6127 / 710c / 712c / 720c / 722c / 815c / 820c / 820ce / 820cxi / 830c / 832c / 850c / 850cxi / 855c / 855cse / 870cse / 870cxi / 880c / 882c / 890cse / 890cxi / 895cse / 895cxi / 9300 / 930c / 930cm / 932c / 935c / 950c / 952c / 955c / 959c / 960c / 970cse / 970cxi / 980cxi / 990cm / 990cxi / 995c / 995ck fax 1220 / 1220xi OfficeJet G55 / G55xi / G85 / G85xi / G95 / K60 / K60xi / K80 / K80xi / pro 1150c / pro 1150cse / pro 1170c / pro 1170cse / pro 1175c / pro 1175cse / pro 1175cxi / R40 / R40xi / R45 / R65 / R80 / R80xi / T45 / T45xi / T65 / T65xi PhotoSmart 1115 / 1215 / 1218 / 1315 / p1000 / p1100
51649A 49		DeskJet 350c / 350cxi / 600 / 600c / 610c / 610CL / 612c / 630c / 632c / 640c / 642c / 648c / 656c / 656cxi / 660c / 660cse / 670c / 670tv / 672c / 680c / 682c / 690c / 692c / 693c / 694c / 695c / 695cxi / 697c DeskWriter 600 / 660c / 670c / 680c / 694c OfficeJet 500 / 520 / 570 / 580 / 590 / 600 / 610 / 630 / 635 / 700 / 710 / 720 / 725 PSC 370 / 380
C1816A 16		DeskJet 350c / 350cxi / 610c / 610CL / 612c / 630c / 632c / 640c / 642c / 648c / 656c / 656cxi / 690c / 692c / 693c / 694c / 695c / 695cxi / 697c DeskWriter 694c OfficeJet 700 / 710 / 720 / 725 PSC 370 / 380
C1823D 23		Color Copier 140 / 145 / 150 / 155 / 160 / 170 / 260 / 270 DeskJet 1120c / 1125c / 710c / 712c / 720c / 722c / 810c / 812c / 815c / 830c / 832c / 880c / 882c / 890cse / 890cxi / 895cse / 895cxi OfficeJet pro 1170c / pro 1170cse / pro 1175c / pro 1175cse / pro 1175cxi / R40 / R40xi / R45 / R65 / R80 / R80xi / T45 / T45xi / T65 / T65xi PSC 500 / 500xi
C3844A		PhotoSmart photo
C3845A		PhotoSmart photo
C4800A 10B		2000 c/cn 2500 c/cm Business Inkjet 2500 DesignJet Colorpro CAD / GA
C4801A 10C		2000 c/cn 2500 c/cm Business Inkjet 2500 DesignJet Colorpro CAD / GA
C4802A 10M		2000 c/cn 2500 c/cm Business Inkjet 2500 DesignJet Colorpro CAD / GA
C4803A 10Y		2000 c/cn 2500 c/cm Business Inkjet 2500 DesignJet Colorpro CAD / GA
C4810A 11B		Business Inkjet 1100 / 1200 / 2200 / 2230 / 2250 / 2280 / 2300 / 2600 Color Inkjet CP1700 DesignJet 100 / 500(PS) / 800(PS) / 815mfp / Copier cc800ps OfficeJet 9110 / 9120 / 9130
C4811A 11C		Business Inkjet 1100 / 1200 / 2200 / 2230 / 2250 / 2280 / 2300 / 2600 Color Inkjet CP1700 DesignJet 100 / 10PS / 120 / 20PS / 500(PS) / 50PS / 800(PS) / 815mfp / Copier cc800ps OfficeJet 9110 / 9120 / 9130
C4812A 11M		Business Inkjet 1100 / 1200 / 2200 / 2230 / 2250 / 2280 / 2300 / 2600 Color Inkjet CP1700 DesignJet 100 / 10PS / 120 / 20PS / 500(PS) / 50PS / 800(PS) / 815mfp / Copier cc800ps OfficeJet 9110 / 9120 / 9130
C4813A 11Y		Business Inkjet 1100 / 1200 / 2200 / 2230 / 2250 / 2280 / 2300 / 2600 Color Inkjet CP1700 DesignJet 100 / 10PS / 120 / 20PS / 500(PS) / 50PS / 800(PS) / 815mfp / Copier cc800ps OfficeJet 9110 / 9120 / 9130
C4920A 14B		Color Inkjet CP1160 Digital Copier Printer 610 OfficeJet 7110 / 7110xi / 7115 / 7130 / 7130xi / 7135xi / 7140xi / D125xi / D135 / D135xi / D145 / D155xi
C4921A 14C		Color Inkjet CP1160 Digital Copier Printer 610

		OfficeJet 7110 / 7110xi / 7115 / 7130 / 7130xi / 7135xi / 7140xi / D125xi / D135 / D135xi / D145 / D155xi
C4922A 14M		Color Inkjet CP1160 Digital Copier Printer 610 OfficeJet 7110 / 7110xi / 7115 / 7130 / 7130xi / 7135xi / 7140xi / D125xi / D135 / D135xi / D145 / D155xi
C4923A 14Y		Color Inkjet CP1160 Digital Copier Printer 610 OfficeJet 7110 / 7110xi / 7115 / 7130 / 7130xi / 7135xi / 7140xi / D125xi / D135 / D135xi / D145 / D155xi
C5023A 12B		Business Inkjet 3000
C5024A 12C		Business Inkjet 3000
C5025A 12M		Business Inkjet 3000
C5026A 12Y		Business Inkjet 3000
C6578A 78A		Color Copier 180 / 190 / 280 / 290 DeskJet 1180 / 1220c / 1220ps / 1280 / 3810 / 3816 / 3820 / 6122 / 6127 / 916c / 920c / 920cvr / 920cxi / 9300 / 930c / 930cm / 932c / 935c / 940c / 950c / 952c / 955c / 959c / 960c / 970cse / 970cxi / 980cxi / 990cm / 990cxi / 995c / 995ck Digital Copier Printer 310 fax 1220 / 1220xi / 1230 / 1230xi OfficeJet 5105 / 5110 / 5110v / 5110xi / G55 / G55xi / G85 / G85xi / G95 / K60 / K60xi / K80 / K80xi / V30 / V40 / V40xi PhotoSmart 1115 / 1215 / 1218 / 1315 / p1000 / p1100 PSC 750 / 750xi / 950 / 950vr / 950xi
C6578D 78		Color Copier 180 / 190 / 280 / 290 DeskJet 1180 / 1220c / 1220ps / 1280 / 3810 / 3816 / 3820 / 6122 / 6127 / 916c / 920c / 920cvr / 920cxi / 9300 / 930c / 930cm / 932c / 935c / 940c / 950c / 952c / 955c / 959c / 960c / 970cse / 970cxi / 980cxi / 990cm / 990cxi / 995c / 995ck Digital Copier Printer 310 fax 1220 / 1220xi / 1230 / 1230xi OfficeJet 5105 / 5110 / 5110v / 5110xi / G55 / G55xi / G85 / G85xi / G95 / K60 / K60xi / K80 / K80xi / V30 / V40 / V40xi PhotoSmart 1115 / 1215 / 1218 / 1315 / p1000 / p1100 PSC 750 / 750xi / 950 / 950vr / 950xi
C6614D 20		DeskJet 610c / 610CL / 612c / 630c / 632c / 640c / 642c / 656c / 656cvr fax 1010 / 1010xi / 1020 / 1020xi / 1040 / 1050 / 925xi
C6615D 15		DeskJet 3810 / 3816 / 3820 / 810c / 812c / 825c / 840c / 841c / 842c / 843c / 845c / 916c / 920c / 920cvr / 920cxi / 940c Digital Copier Printer 310 fax 1230 / 1230xi OfficeJet 5105 / 5110 / 5110v / 5110xi / V30 / V40 / V40xi PSC 500 / 500xi / 750 / 750xi / 950 / 950vr / 950xi
C6625A 17		DeskJet 825c / 840c / 841c / 842c / 843c / 845c
C6628A 19		DeskJet 350c / 350cbi
C6656A 56		DeskJet 450cbi / 450ci / 450WBt / 5150 / 5150c / 5160 / 5550 / 5551 / 5650 / 5650v / 5652 / 5850 / 7450 / 9650 / 9670 / 9680 Digital Copier Printer 410 fax 1240 OfficeJet 4105 / 4105z / 4110 / 4110xi / 4115 / 4211 / 4212 / 4215 / 4215v / 4215xi / 4219 / 4251 / 4252 / 4255 / 4259 / 5505 / 5508 / 5510 / 5510v / 5510xi / 5515 / 6110 / 6110v / 6110xi PhotoSmart 5150 / 7150 / 7260 / 7350 / 7450 / 7550 / 7660 / 7755 / 7760 / 7960 PSC 1110 / 1110v / 1110xi / 1209 / 1210 / 1210v / 1210xi / 1215 / 1311 / 1312 / 1315 / 1317 / 1318 / 1340 / 1345 / 1350 / 1350v / 1350xi / 1355 / 2105 / 2110 / 2110v / 2110xi / 2115 / 2170 / 2171 / 2175 / 2175v / 2175xi / 2210 / 2210v / 2210xi / 2405 / 2410 / 2410v / 2410xi / 2420 / 2510 / 2510xi
C6657A 57		DeskJet 450cbi / 450ci / 450WBt / 5150 / 5150c / 5160 / 5550 / 5551 / 5650 / 5650v / 5652 / 5850 / 7450 / 9650 / 9670 / 9680 Digital Copier Printer 410 fax 1240 OfficeJet 4105 / 4105z / 4110 / 4110xi / 4115 / 4211 / 4212 / 4215 / 4215v / 4215xi / 4219 / 4251 / 4252 / 4255 / 4259 / 5505 / 5508 / 5510 / 5510v / 5510xi / 5515 / 6110 / 6110v / 6110xi PhotoSmart 100 / 130 / 145 / 230 / 245 / 5150 / 7150 / 7260 / 7350 / 7450 / 7550 / 7660 / 7755 / 7760 / 7960 PSC 1110 / 1110v / 1110xi / 1209 / 1210 / 1210v / 1210xi / 1215 / 1311 / 1312 / 1315 / 1317 / 1318 / 1340 / 1345 / 1350 / 1350v / 1350xi / 1355 / 2105 / 2110 / 2110v / 2110xi / 2115 / 2170 / 2171 / 2175 / 2175v / 2175xi / 2210 / 2210v / 2210xi / 2405 / 2410 / 2410v / 2410xi / 2420 / 2510 / 2510xi

C6658A 58		DeskJet 3620v / 3650 / 450cbi / 450ci / 450WBt / 5150 / 5150c / 5160 / 5550 / 5551 / 5650 / 5650v / 5652 / 5850 / 7450 / 9650 / 9670 / 9680 Digital Copier Printer 410 OfficeJet 4211 / 4212 / 4215 / 4215v / 4215xi / 4219 / 4251 / 4252 / 4255 / 4259 / 6110 / 6110v / 6110xi PhotoSmart 7150 / 7260 / 7350 / 7450 / 7550 / 7660 / 7755 / 7760 / 7960 PSC 1311 / 1312 / 1315 / 1317 / 1318 / 1340 / 1345 / 1350 / 1350v / 1350xi / 1355 / 2105 / 2110 / 2110v / 2110xi / 2115 / 2170 / 2171 / 2175 / 2175v / 2175xi / 2210 / 2210v / 2210xi / 2405 / 2410 / 2410v / 2410xi / 2420 / 2510 / 2510xi
C8727A 27		DeskJet 3320 / 3325 / 3420 / 3425 / 3450 / 3520 / 3550 / 3550v / 3620v / 3650 / 3740 / 3745 / 3843 / 3845 fax 1240 OfficeJet 4105 / 4105z / 4110 / 4110xi / 4115 / 4211 / 4212 / 4215 / 4215v / 4215xi / 4219 / 4251 / 4252 / 4255 / 4259 PSC 1110 / 1110v / 1110xi / 1210 / 1210v / 1210xi / 1215 / 1311 / 1312 / 1315 / 1317 / 1318 / 1340 / 1345 / 1350 / 1350v / 1350xi / 1355 / 2105 / 2110 / 2110v / 2110xi / 2115 / 2170 / 2171 / 2175 / 2175v / 2175xi / 2210 / 2210v / 2210xi
C8728A 28		DeskJet 3320 / 3325 / 3420 / 3425 / 3450 / 3520 / 3550 / 3550v / 3620v / 3650 / 3740 / 3745 / 3843 / 3845 fax 1240 OfficeJet 4105 / 4105z / 4110 / 4110xi / 4115 / 4211 / 4212 / 4215 / 4215v / 4215xi / 4219 / 4251 / 4252 / 4255 / 4259 PSC 1110 / 1110v / 1110xi / 1209 / 1210 / 1210v / 1210xi / 1215 / 1311 / 1312 / 1315 / 1317 / 1318 / 1340 / 1345 / 1350 / 1350v / 1350xi / 1355 / 2105 / 2110 / 2110v / 2110xi / 2115 / 2170 / 2171 / 2175 / 2175v / 2175xi / 2210 / 2210v / 2210xi
C8765E 338		DeskJet 5740 / 6540 / 6620 / 6840 OfficeJet 6210 / 7310 / 7410 PhotoSmart 2610 / 2710 / 8150 / 8450 PSC 1510 / 2355
C8766E 343		DeskJet 5740 / 6540 / 6620 / 6840 OfficeJet 6210 / 7310 / 7410 PhotoSmart 2610 / 2710 / 325 / 375 / 8150 / 8450 / 8750 PSC 1510 / 2355
C8767E 339		DeskJet 5740 / 6540 / 6620 / 6840 OfficeJet 7310 / 7410 PhotoSmart 2610 / 2710 / 8150 / 8450 / 8750
C9351A 21		DeskJet 3910 / 3918 / 3920 / 3930 / 3930v / 3938 / 3940 / 3940v PSC 1410
C9352A 22		DeskJet 3910 / 3918 / 3920 / 3930 / 3930v / 3938 / 3940 / 3940v PSC 1410
C9359A 59		PhotoSmart 145 / 245 / 7660 / 7755 / 7760 / 7960
C9361E 342		DeskJet 5440 PhotoSmart 2575 PSC 1510
C9362E 336		DeskJet 5440 PhotoSmart 2575 PSC 1510
C9363E 344		DeskJet 5740 / 6540 / 6620 / 6840 OfficeJet 6210 / 7310 / 7410 PhotoSmart 2610 / 2710 / 325 / 375 / 8150 / 8450 / 8750 PSC 2355
C9368A 100		DeskJet 6540 / 6543 / 6620 / 6840 / 6843 OfficeJet 7310 / 7410 PhotoSmart 2610 / 2710 / 325 / 375 / 8150 / 8450 / 8453 / 8750
C9369E 348		DeskJet 5740 / 6540 / 6620 / 6840 OfficeJet 6210 / 7310 / 7410 PhotoSmart 2610 / 2710 / 8150 / 8450 / 8750 PSC 1510 / 2355